XKELEX XZ19PF Aluminum Attachment System with Rivets





Fiber Cement Ventilated Rainscreen System



Typical Details

Page 3: Top Panel @ Coping Page 4: Top Panel @ Soffit Page 5: Top of Panel @ F.C.P Soffit Page 6: Horizontal Panel Joint Page 7: Horizontal of Panel @ Wall Base Page 8: Bottom of Panel @ Open Termination Page 9: Bottom of Panel @ Low Roof Flashing Page 10: Bottom of Panel @ Soffit Page 11: Bottom of Panel @ Soffit (Alternate) Page 12: Bottom of Panel @ F.C.P Soffit Page 13: Bottom of Panel @ F.C.P Soffit (Alternate) Page 14: Soffit Termination @ Adjacent Material Page 15: Bottom of Panel @ Window Head Page 16: Bottom of Panel @ Window Head (Alternate) Page 17: Top of Panel @ Window Sill Page 18: Panel Edge @ Window Jamb Page 19: Panel Edge @ Window Jamb (Alternate) Page 20: Vertical Joint @ Continuous Substrate Page 21: Vertical Joint @ Break in Substrate Page 22: Not Permitted @ Break in Substrate Page 23: Panel Edge @ Butt Joint Page 24: Panels @ Outside Corner Page 25: Panels @ Inside Corner Page 26: Typical Fastener Layout

















































