# One Layer Steel Attachment System with Rivets








## **Typical Details**

- Page 3: Top Panel @ Coping
- Page 4: Top Panel @ Soffit
- Page 5: Top of Panel @ F.C.P Soffit
- Page 6: Horizontal Joint @ Continuous Substrate
- Page 7: Horizontal Joint @ Break In Substrate
- Page 8: Not Permitted @ Break in Substrate
- Page 9: Bottom of Panel @ Wall Base
- Page 10: Bottom of Panel @ Open Termination
- Page 11: Bottom of Panel @ Low Roof Flashing
- Page 12: Bottom of Panel @ Soffit
- Page 13: Bottom of Panel @ Soffit (Alternate)
- Page 14: Bottom of Panel @Soffit
- Page 15: Bottom of Panel @ F.C.P Soffit
- Page 16: Bottom of Panel @ F.C.P Soffit (Alternate)
- Page 17: Soffit Termination @ Adjacent Material
- Page 18: Bottom of Panel @ Window Head
- Page 19: Bottom of Panel @ Window Head (Alternate)
- Page 20: Top of Panel @ Window Sill
- Page 21: Panel Edge @ Window Jamb
- Page 22: Panel Edge @ Window Jamb (Alternate)
- Page 23: Vertical Panel Joint Option 1
- Page 24: Vertical Panel Joint Option 2
- Page 25: Panel Edge @ Butt Joint
- Page 26: Panels @ Outside Corner
- Page 27: Panels @ Inside Corner
- Page 28: Typical Fastener Layout







(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ret.:

Top of Panel @ Coping

## One Layer Steel Attach System-Rivets






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ret.:

Top of Panel@ Soffit






#### NOTES:

1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.




(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ret.:


Top of Panel @ F.C.P Soffit





(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.: Horizontal Joint @ Continuous Substrate






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref ·

Horizontal Joint @ Break in Substrate






## NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Not Permitted @ Break in Substrate





#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.




(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com

Bottom of Panel @ Wall Base

## One Layer Steel Attach System-Rivets





#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Bottom of Panel @ Open Termination


## One Layer Steel Attach System-Rivets






(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Bottom of Panel @ Low Roof Flashing






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Bottom of Panel @ Soffit






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Bottom of Panel @ Soffit(Alternate)






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ret.:

Bottom of Panel @ Soffit






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ret.:

Bottom of Panel @ F.C.P Soffit






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Bottom of Panel @ F.C.P Soffit(Alternate)





#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.




(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Soffit Termination @ Adjacent Material

## One Layer Steel Attach System-Rivets






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref :

Bottom of Panel @ Window Head





#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.




(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com

## Ref.:

Bottom of Panel @ Window Head (Alternate)






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Top of Panel @ Window Sill






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Panel Edge @ Window Jamb






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Vertical Panel Joint Option 1






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Vertical Panel Joint Option-2






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref :

Panel Edge @ Window Jamb Alternate






#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Panel Edge @ Butt Joint






#### NOTES:

1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Panels @ Outside Corner





#### NOTES:


1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.




(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com Ref.:

Panel @ Inside Corner

# Typical Steel And Aluminum Attachment System






Typical Edge Fastners
Scale 3"=1'

#### DRILLING KEY

Metal (Steel and Aluminum) — Fixed Points 8.3 mm (Drill Bit Sourced from AFCC), Gliding Points 12mm (Drill Bit Sourced from AFCC)



#### NOTES:

1. PANEL VERTICAL AND HORIZONTAL JOINT SPACING SHOULD BE 3/8" TYPICAL.



(303) 972-5107 6901 S Pierce St #180 Littleton, CO 80128 www.americanfibercement.com ≺et.:

Typical Fastner layout